

# Stifle Fitting with Hyperextension Tarsal Cuff



1. Place foot through bottom hole of brace



2. Position back cuff to rest above metatarsal heads




3. Fasten bottom strap(s)




4. Fasten strap around the tarsus (ankle)  
Do not pull too tight or you may irritate the Achilles tendon



5. Push knee hinges onto the knee as far as you can. While holding the brace in that position, fasten the back middle strap SNUG



6. Push thigh cuff onto leg. Squeeze brace inward and fasten top strap SNUG



7. Fasten front knee strap. Do not pull too tight or you will pull the brace forward off the knee. The pad should be directly touching the tibia (shin)